



**Cumberland Valley Analytical Services, Inc.**

800-282-7522

301-790-1980

[www.foragelab.com](http://www.foragelab.com)

[mail@foragelab.com](mailto:mail@foragelab.com)

*Mailing & UPS/FedEx Address:*

4999 Zane A. Miller Drive

Waynesboro, PA 17268

## Water Sample Submittal Form

Use one form per sample

*Please clearly provide complete contact information*

<b>Lab Use</b>
Date Received _____
Time Received _____
Sample ID _____
Mail Charge _____

<b>Party to Bill</b>	<b>Preferred Reporting Method (s)</b> <input type="checkbox"/> Mail <input type="checkbox"/> Fax <input type="checkbox"/> Email <input type="checkbox"/> Internet
Account #	
Name	
Street	
City	
State                      Zip	
Phone	
Fax	
Email	

<b>Copy 1</b>	<b>Preferred Reporting Method (s)</b> <input type="checkbox"/> Mail <input type="checkbox"/> Fax <input type="checkbox"/> Email <input type="checkbox"/> Internet
Account #	
Name	
Street	
City	
State                      Zip	
Phone	
Fax	
Email	

<b>Copy 2</b>	<b>Preferred Reporting Method (s)</b> <input type="checkbox"/> Mail <input type="checkbox"/> Fax <input type="checkbox"/> Email <input type="checkbox"/> Internet
Account #	
Name	
Street	
City	
State                      Zip	
Phone	
Fax	
Email	

<b>Farm/Client:</b>
<b>Sample Description/Source:</b>
<b>Date and Time Collected:</b>

<b>Water Analysis Requested</b>
<input type="checkbox"/> pH
<input type="checkbox"/> pH and Nitrate Nitrogen
<input type="checkbox"/> Coliform/E.coli quantitative count <b>(we provide sterile 100ml bottle needed)</b>
<input type="checkbox"/> Water Suitability Package <i>pH, Hardness, Total Dissolved Solids, Ca, Mg, K, Na, Fe, P, Mn, Zn, Cu, Chlorides, Sulfates, Nitrates (need 500ml bottle)</i>
<input type="checkbox"/> Alkalinity

<b>Other Charges:</b>
US Mail Priority Fee <i>(at US mail Rates)</i>
UPS Ground Service
UPS Next Day Service

Included are sample bottles and shipping labels. Shipping charges using our UPS/US Mail labels are billed back at the rates listed. **Water samples should arrive at the lab within 24 hours. 100ml sterile bottles are needed for the bacterial analyses and 500ml bottles are needed for all other water analyses. Refrigerate samples and keep cool during transit to the lab. Please follow water sampling instructions when collecting your sample to avoid contamination and cushion bottles adequately to avoid breakage during shipment.**